

Mitsubishi Pajero 3.2DI-D 170HP 2007

1. Find plug for rail pressure sensor. Disconnect it and connect box adapter between.

